



Commins

®

AUTOTIGHT

ROD HOLDDOWN SYSTEMS

Free Displays for Qualified Builders & Engineers.

Nothing shows the ease of installation better than a working sample. We give free working samples to qualified engineers, builders, specifiers and inspectors. One installation will show you why this is the best system available



Installation: The AT Auto Take-Up is placed over a threaded rod onto a steel plate. A Nut and washer follows and is tightened. To activate, remove the screw. (Use a # 2 Phillips driver)

Installation time: 20 to 30 sec.!

Expansion: Press on the wood “floor” slowly and gently to see the AT Auto Take-Up function. As the wood “shrinks” and building settles the AT expands to fill the gap.

AutoTight® Faster,
Simple, More Reliable.

To reset the AT, remove the device from the rod, insert the pin wrench into the bottom of the AT and turn the stud back into the body. Once the AT is bottomed insert the screw into the hole and lock the parts together.

Please reset the AT after a demonstration.



Expanded AutoTight Take-Up

Commins Manufacturing Inc
960 B Guard Street
Friday Harbor, WA 98250

Phone 360.378.9484
Fax: 360.378.9485
www.comminsmfg.com